

MEZGER Heftsysteme GmbH

Saganer Straße 24 D-90475 Nürnberg

Tel. +49 911 98494-0 Mail <u>info@mezger.eu</u> Postfach (P.O.B.) 551170 D-90218 Nürnberg

Fax +49 911 98494-30 Internet www.mezger.eu MG[®]
Blind Stapling

INFO 907 Pos 5.7 Pos 2.10 Pos A1+2.6

For closing filled folding boxes there is no possibility to clinch the staple on a customary counter-pressure. There are two different systems to effect the staple clinch from outside:

- **1.** Common system by means of clinching anvils: A staple with straight legs is being bent by clinching anvils inserted from outside see Anvil System. MEROLOCK 3, MEPA, MEPA P and JUMBO, Stapling heads LRS + LRW for coiled staples.
- **2.** MG[®] Blind Stapling System: A specially preformed TOP staple is being automatically clinched see models Blind Staplers TOP, TOP EH and TOP P as well as Stapling Heads E 24-60 for coiled staples.
- The specially shaped staple is automatically clinched within the corrugated section of the under board without piercing through the cardboard.
- This enables perfect blind stapling without customary clinching anvils.
- There are no additional stitching holes next to the staple as known with the anvil system.
- This prevents damage by the anvils as they inevitably destroy the cardboard partially and weaken the stability of the stapled box.
- Empty folding boxes can also be bottom-stapled. Staple from inside to outside TOP EH and TOP P or the folding box is being put over a wooden horse and stapled from outside.
- No clinching anvils means less parts subject to wear and tear hence higher availability of the stapler.



Pos 5 >





Pos Aut 1 + 2: Heftautomat E 24-60 /4 für den gleichzeitigen Bodenund Deckelverschluss gefüllter Faltschachteln unterschiedlicher Größen aus Wellpappe.











